




The application of the KIT Elpro S40 / S50 MASTER - SLAVE makes it possible to control, by means of two Elpro S40 / S50 boards, up to 8 retractable bollards simultaneously.

This instructions sheet refers solely and exclusively to the MASTER/SLAVE connections of the Elpro S40 / S50 control board. For complete information regarding electrical connections, functions setting and diagnostic on the Elpro S40 / S50 reference should be made to the instructions provided with the product.


Plug-in PCB for traffic light
provided with the KIT
Elpro S40 / S50
MASTER - SLAVE



(Optional: Plug-in PCB
for traffic light to suit
230 V lamp)
code 7282L



For the Elpro S50.EFO, make the connections in the dedicated terminal block, external to the Elpro S40.



Note well: whenever Elpro S40 / S50 is re-powered, wait 10 seconds for the logic to become fully operating again.

It is IMPORTANT to distinguish the Elpro S40 / S50 MASTER which commands the Elpro S40 / S50 SLAVE by means of the traffic light control card provided with the KIT Elpro S40 / S50 MASTER - SLAVE. All the accessories for command and safety must be connected to the terminals of the Elpro S40 / S50 MASTER that manages and controls the entire system. Signalling accessories as LEDs and/or buzzer are connected respectively to the Elpro S40 / S50 MASTER or SLAVE of the bollards it commands. A possible plug-in traffic light control card is to be connected to the Elpro S40 / S50 SLAVE.

KIT Elpro S40 / S50 MASTER-SLAVE application:

1. Replace the standard Elpro S40 / S50 microprocessors with the Elpro S40 / S50 MASTER and SLAVE from the KIT on the respective Elpro S40 / S50 control boards.
2. Insert the traffic light control card provided with the KIT into dedicated connector on the Elpro S40 / S50 MASTER board and perform electrical connections as illustrated in the picture.
3. Set working time on the Elpro S40 / S50 SLAVE on maximum.
4. Set all the dip-switches of the Elpro S40 / S50 SLAVE in OFF.
5. Configure the dip-switches for the desired functions only on the MASTER board.
6. If new working time setting should be required, use only the trimmer on the Elpro S40 / S50 MASTER board.
7. Adjust PAUSE time on the Elpro S40 / S50 MASTER control board.