**EAGLE ARTEK** CEILING ACCESSORY

DIMENSIONS

Ø 5″


Ø 7.5"

ENGLISH


1″




Visit website for available languages of this document.



## **INSTALLATION**




Place the mounting template in the desired mounting location and make the appropriate cuts.



Secure the ceiling accessory to the ceiling using the provided screws and wingnuts.




Route and connect the harness to the sensor, and then secure the sensor in the ceiling accessory.



Make the appropriate radar adjustments to create the desired field shape and position. *Tilt angle should be 70° for optimal performance.* 

Connect the EAGLE ARTEK harness to the ceiling accessory.



Snap the Ceiling Accessory cover to the Ceiling Accessory housing.



