

## Maximum RFID

# UHF CREDENTIALS for VEHICLE MOUNTING with LR-2000, LR-3000 & LR-3200 READERS

### WS-UHF-0-0 Windshield Tag

- Self-adhesive — tag adheres permanently **inside windshield glass**
- Tag is destroyed if it is ripped off windshield after adhesive cures
- Hands-free identification — out of driver's line of sight
- Secure tag — for one-time use — slits give evidence of tampering



### RV-UHF-0-0 Rearview Mirror Tag

- Tag adheres permanently on shell of rear-view mirror
- Self-adhesive — tag is destroyed if it is pulled off after curing
- Hands-free identification — **low visibility** — black side faces reader
- Secure tag permanently attached inside or outside the vehicle



### MT-UHF-0-0 Metal-Mount Tag

- Bar-type tag — variety of locations and fastenings — reads **on metal**
- Self-adhesive — also held by screws, rivets, cable ties ...
- Use inside or outside on front, side or top of vehicles
- For big trucks, buses, forklifts, containers, golf carts, wheelchairs ...



### SV-UHF-0-0 Sideview Mirror Tag

- Tag adheres permanently on edge of mirror shell
- Self-adhesive — tag is disabled if pulled off after adhesive cures
- Hands-free — small, thin, simple, **out of sight** under mirror
- Secure tag — flexible use in other outside locations



### PT-UHF-0-0 Portable Tag

- Tag installs like a toll highway tag on windshield behind mirror
- Hook-and-loop adhesive strip holds tag firmly in reading position
- Hands-free use inside vehicles — **move tag** easily to other vehicles
- For readers installed above the traffic lane or at either side



### VT-UHF-0-0 Sunvisor Tag

- Hand-held — tag can be held by fingertips on clip — or ...
- Hands-free — tag clips to sunvisor — easily moved to other vehicles
- Clip holds tag facing reader through windshield when visor is down
- Lower visor to read tag — tag is **out of sight** when not reading



### HT-UHF-0-0 Hangtag

- Tag hooks on rearview mirror's post — easily moved or carried
- Hook lets tag hang free — to read, driver can turn tag by fingers
- Hands-free identification — also portable like a card — hold to read
- Visible through windshield** for printed or laminated identification



### ST-UHF-0-0 Supertag

- Large tag with **superior read range** in tough assignments
- Attaches by double-side adhesive tape, screws, rivets, cable ties ...
- Permanent or temporary mounting — for rugged use and bad weather
- Perfect in industrial and commercial applications — inside or outside



# Maximum RFID

NOTE: For UHF credentials held by hand, see product sheet "UHF Credentials for Holding by Hand". For vehicle-mounted tags, see below.  
Reading Distances – Up to These Distances in Practical Applications

| Tag ... Conditions            | LR-2000, LR-3000, LR-3200 | uAccess Readers  |
|-------------------------------|---------------------------|------------------|
| WS-UHF-0-0 on windshield      | 25 feet (7.6 meters)      | (Not applicable) |
| RV-UHF-0-0 on mirror shell    | 20 feet (6.1 meters)      | (Not applicable) |
| MT-UHF-0-0 on metal surface   | 15 feet (4.6 meters)      | (Not applicable) |
| SV-UHF-0-0 on sideview mirror | 25 feet (7.6 meters)      | (Not applicable) |
| PT-UHF-0-0 on windshield      | 15 feet (4.6 meters)      | (Not applicable) |
| VT-UHF-0-0 clipped on visor   | 15 feet (4.6 meters)      | (Not applicable) |
| HT-UHF-0-0 hanging on mirror  | 10 feet (3.0 meters)      | 6 inches (15 cm) |
| ST-UHF-0-0 fastened on metal  | 35 feet (10.7 meters)     | (Not applicable) |

**Reader Selection** With vehicle-mounted tags, use LR-2000, LR-2200, LR-3000, and their "HiLo" variations.

## Technology in Tags and Cards

- ] UHF communications: Bi-directional between UHF readers and credentials.
- ] Excitation frequency: 865-868 MHz for the LR-2200 reader; 902-928 MHz for other UHF readers.
- ] Read repetition rate: Set in the readers. For "LR" readers, rep rate is 3 reads per second (field-programmable to slower rates).

## Encoding for Tags

- ] Code format type – Wiegand. • Open code formats – 26-bit-STD and 37-bit-AWI. • For a custom format, call AWID.

## Information Required in Purchase Order (Include leading zeros in facility code and ID numbers.)

- ] Quantity. • AWID's part no. • Code format (example: 26-bit-STD). • Facility or site code. • Start ID number sequence.

## Size of Tags and Cards (Approximate)

| Tag        | Width         | Height       | Thickness  | Notes                                 |
|------------|---------------|--------------|------------|---------------------------------------|
| WS-UHF-0-0 | 4 inches      | 1 inch       | <1/32 inch | Peel-off sheet covers adhesive.       |
| RV-UHF-0-0 | 4-3/16 inches | 1-1/8 inches | <1/32 inch | Peel-off sheet covers adhesive.       |
| MT-UHF-0-0 | 8 inches      | 15/16 inch   | 1/4 inch   | Self-adhesive. 2 holes for fasteners. |
| SV-UHF-0-0 | 4-3/8 inches  | 1/2 inch     | <1/32 inch | Peel-off sheet covers adhesive.       |
| PT-UHF-0-0 | 3-1/8 inches  | 1-5/8 inches | 3/8 inch   | Peel-off sheet covers adhesive strip. |
| VT-UHF-0-0 | 4-1/2 inches  | 2-3/8 inches | 1/32 inch  | Includes U-clip for sunvisor.         |
| HT-UHF-0-0 | 2-1/4 inches  | 6-1/2 inches | 1/32 inch  | With hook to hang on mirror.          |
| ST-UHF-0-0 | 5-1/2 inches  | 7-3/4 inches | 3/4 inch   | Flat back. 4 holes for fasteners.     |

## Slots and Holes

- ] WS-UHF, RV-UHF, SV-UHF, PT-UHF, HT-UHF: Must have **no slots or holes**, punched or drilled.
- ] VT-UHF: **Contains a slot** for the sunvisor clip (supplied with the tag).
- ] MT-UHF, ST-UHF: **Contains holes** at the ends for screws, rivets, cable ties. Must not be punched or drilled.

## Applications

- ] Use tags on cars, trucks, buses, fire trucks, forklifts, motorcycles, golf carts, transit vehicles, wheel chairs, gurneys, rail cars, etc.
- ] For security, **WS-UHF** and **RV-UHF** tags tear when they are ripped from their cured adhesive. **SV-UHF** tag is for one-time use only.
- ] For user convenience, all other tags may be moved easily from one vehicle to another vehicle.
- ] Tag type and mounting location must be consistent for all readers in a particular installation.
- ] If used with a "HiLo" reader (dual antennas), credentials may be different types, in different locations, on different vehicle types.

## Custom Graphics

- ] For quotation, send original artwork to AWID. ] A local printer may be able to print graphics. ] Not for ST-UHF tag.

## Literature for UHF Credentials

- ] Before installing any tag, read AWID's "Installation Instructions" sheet for that tag type.

## Options and Accessories

- ] LR-TEK LR Reader Tech Kit: Required -- a one-time purchase for every installing dealer.