

CW-SYS to DoorKing 9150 Control Panel

CW-INT

Terminals 1 & 2 are AC/DC input power.

Terminal 4: Relay Common

Terminal 5: Relay Normally Open

