

LIGHT DUTY SPRING GATE CLOSER

A simple gate closer that can be easily welded to small gates and fabrications for a simple and reliable close

Supplied assembled to be welded onto the gate and then galvanised and/or painted as part of the gate

Adjustable spring tension - Easily adjust spring tension on site by lifting and rotating the adjuster wheel

PRODUCT DETAILS

Product code:	Description:
LDSGCL	Light Duty spring gate closer left hand
LDSGCR	Light Duty spring gate closer right hand

Max gate weight: 50kg

Finish: Mild steel



INSTALLATION

1. With the domed cap facing upwards, weld the lower of the top brackets and the lower of the bottom brackets to the gate post.
2. Weld the second 2 brackets to the gate.
3. Adjust the tension as needed, see below.

ADJUSTING THE TENSION

To adjust the spring tension, simply lift the adjuster wheel at the bottom of the closer and rotate to tighten or loosen the spring, before dropping the pin back into one of the location holes.

This can be adjusted at any time after installation if needed.

MAINTENANCE

Spray mechanism with a light oil every 6 months.

