

Specifications

Frequency: 433.39 MHz.

Security: 128-bit AES encryption.

Range: up to 50 yards.

Battery life: up to 3 years.

Battery type: Eveready AA Lithium 1.5V x 2.

Important: Use only AA 1.5V Lithium batteries – do not use Alkaline batteries.



e-LOOP Mini Fitting Instructions

1. Hold the e-Loop next to the antenna of the transceiver
2. Now press and release the CODE button on the transceiver or gate controller. The e-Loop will flash the Yellow LED and the transceiver will flash the Blue LED 3 times. If coding to the gate controller with LCD screen, the screen will display 'LOOP PAIRED'. The system is now coded.


Step 2 - Fitting the e-LOOP Mini bases plate to the driveway

1. Face the arrow on the base plate towards the gate. Using a 0.1" (0.5cm) concrete masonry drill, drill the two mounting holes 5.5cm deep, then use the 2.1" concrete screws supplied to fix into the driveway.

Step 3 - Fitting the e-LOOP Mini to base plate

(Refer to the diagram on the right)

1. Now fit the e-loop Mini to the base plate using the 4 hex screws supplied, making sure the arrow also points towards the gate (this will ensure keyway is aligned). The e-Loop will become active after 3 minutes.



NOTE: Ensure hex screws are tight as this forms part of the water-sealing process.



IMPORTANT: Never fit near high voltage cables, this can affect the e-Loop's vehicle detection and radio range capabilities.



IMPORTANT: This product can expose you to chemicals including Acrylonitrile.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from
- that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with a minimum distance between 20cm of the radiator and your body: Use only the supplied antenna.

